

### Supported Plug-in Kits for MXview 2.3

Series	Model Name	Firmware
MGate MB3000 Series	MGate MB3170	v2.1 or higher
	MGate MB3180	v1.3 or higher
	MGate MB3270	v2.1 or higher
	MGate MB3280	v2.1 or higher
	MGate MB3480	v2.1 or higher
MGate 5000 Series	MGate 5105-MB-EIP	v1.0 or higher
	MGate 5101-PBM-MN	v1.0 or higher
MGate EIP3000 Series	MGate EIP3170	v1.0 or higher
	MGate EIP3170I	v1.0 or higher
	MGate EIP3270	v1.0 or higher
	MGate EIP3270I	v1.0 or higher

### Supported Plug-in Kits for MXview 2.2

Series	Model Name	Firmware
NPort 5000AI-M12 Series	NPort 5150AI-M12/ 5250AI-M12/5450AI-M12	v1.0 or higher
NPort 5000 Series	NPort 5110	v2.4 or higher
	NPort 5130/5150	v3.4 or higher
	NPort 5210/5230/5232	v2.6 or higher
	NPort 5410/5430/5450	v3.9 or higher
	NPort 5600-8-DT/5650-8-DT	v2.2 or higher
	NPort 5600	v3.5 or higher
	NPort 5610-8-DTL/5650-8-DTL	v1.1 or higher
NPort 5000A Series	NPort 5110A/5130A/5150A	v1.1 or higher
	NPort 5210A/5230A/5250A	v1.1 or higher
NPort IA5000 Series	NPort IA5150/IA5250	v1.4 or higher
NPort IA5000A Series	NPort IA5150A/IA5250A	v1.1 or higher
	NPort IA5450A	v1.2 or higher
NPort 6000 Series	NPort 6150/6250/6450	v1.9 or higher
	NPort 6610-8/6610-16/6610-32	v1.9 or higher
	NPort 6650-8/6650-16/6650-32	v1.9 or higher